

# MOBILE PROBLAST

## PORTABLE MICROABRASIVE SANDBLASTER PART NUMBER 80017

A micro air abrasion sandblaster that goes wherever your air compressor can reach. High quality for professionals, affordable for hobbyists.

- 1,000 mL media tank
- Pencil-style precision nozzle
- 6-ft. handpiece reach
- Foot pedal start/stop
- Low cost maintenance
- Different media size tanks and nozzle tips available
- Instant-Off "Master" variant available



### SIZE

L 8" x W 6" x H 10.5"  
(203 mm x 152 mm x 267 mm)



10 lbs.  
(4.5 kg)



Vaniman  
warranty



0-100 PSI



Air compressor  
required\*



MASTER MOBILE PROBLAST: PN 80031

## MEDIA TYPES

available from Vaniman:

- Aluminum Oxide
- Sodium Bicarbonate
- Glass Beads
- Walnut Shell

Our sandblasters can be used with any dry media type within the size range specific to the tank and tip (25-50  $\mu$ m, 50-100  $\mu$ m, or 110-250  $\mu$ m).

Vaniman's Mobile Problast is the perfect micro sandblaster for fossil preparation and matrix removal, glass etching and carving, marine applications that require the removal of biofilm, tool cleaning, appliance cleaning, post-print parts processing, marking, polishing, peening, smoothing, sharpening, deburring, deoxidizing, and tons of other uses.

For those looking for greater control for more delicate projects, the Master Mobile Problast provides consistently pressured Instant-Off media flow. Glass Etcher variant (PN 80038) also available.

\* Air compressor required (not included). Compressed air requirements: minimum 90 PSI at 1.5 CFM (recommended 2.5 CFM).